


Functions for ControLaser Zoom Camera AC3 and iSmart Duo Camera:



Cable Info

Signal
+UB
GND
RS485+
RS485-



Color
Brown
White
Yellow
Green
Shield/Black

Functions for ControLaser Robot 336 / 640:

FLR.006036/
FLR.006400



F1:
Press for 1 second to switch the temperature display (bar, digital, combined) Press and hold for 10 seconds, switch to ISO-therm colors

F2 / F3:
Not used



Joystick:
Move image in digital zoom
(up, down, left, right)

Zoom + (IN)
Zoom - (OUT)

Color Pattern + (UP)
Color Pattern - (DOWN)

Cable Info BNC/RS485

Signal
+UB
GND
RS485+
RS485-
Video
Zoom
Color Pattern



Color
Red
Black
Yellow
Blue
BNC
Grey
Orange

> control via GND